



TRAVEL HAMMOCK INSTRUCTIONS

SAFETY INSTRUCTIONS

1. Do not exceed the maximum load.
2. Do not climb into hammock feet first.
3. Do not dive into or jump about in hammock.
4. Do not stick your head through the end strings.
5. Do not pull yourself up by the rod (hammock chairs).
6. Keep end strings as straight as possible, do not twist.
7. Do not use damaged or weakened hammock hanging accessories.
8. Hammocks are not designed for swinging.
9. Do not leave children unattended in hammock or near hammock.
10. Hammock fabrics and accessories will become worn over time and use.
Always check the loading capacity before use.
11. When installing always check with a qualified builder if unsure of safety.
12. If possible, only use the hammock on floors with shock-absorbing properties such as carpet or outdoor grass to minimise the risk of injury in case of falling out of the hammock.

THE TWO TREES HAMMOCKS RANGE INCLUDES



Made in China exclusively for
Mayo Hardware Pty Ltd
4 Secombe Place, Moorebank
NSW 2170 Australia
Customer Service Phone:
1300 360 211
www.mayohardware.com.au

2017®



For more information visit
www.twotreeshammocks.com.au

We will honour all statutory guarantees
that this product is of acceptable quality.
(including that it is fit for purpose)




TRAVEL HAMMOCK INSTRUCTIONS


At Two Trees we know the importance of spending time relaxing. That's why we've developed a range of quality hammocks and convenient accessories that come with easy to follow installation instructions so you will be relaxing in no time.

THINGS TO CONSIDER

- Do not twist or knot suspension cords when hanging.



- Travel hammocks are hung with sag.



- Hammocks will stretch by 5-10% in use.
Adjust the mounting accordingly after each use to keep you and your hammock comfortable.





HOW TO HANG YOUR HAMMOCK

To hang your Two Trees hammock you will require two fixed points, such as trees, beams, or posts.

Your Two Trees hammock will require approximately 4 metres between fixing points to get the ideal shape.

Hang the hammock loops at roughly the same height. When the hammock is in use it should sit 20-30cm above the ground.





Figure 1




Figure 2

1. On each end of the hammock, tie two basic overhand knots (as close together as possible) approximately 10cm from the end of the rope to form a double knot – see figure 1.
2. Wind ropes on each end of the hammock around a fixed point (e.g. tree trunks). Loop the rope end through the knot and tighten the ropes to ensure that the ropes will not slip downwards before using hammock.
3. Hook and lock the carabiner into the ropes as shown in figure 1. Ensuring that the hook opening is pointing downwards.


WARNING: DO NOT EXCEED THE MAXIMUM LOAD

We at Two Trees know the importance of spending time relaxing. We've developed a range of quality hammocks and convenient accessories that come with easy to follow installation instructions so you'll be relaxing in no time at all.

HOW TO RELAX IN YOUR HAMMOCK

1. Open the fabric in the centre of the hammock, and sit in the middle as you would in a chair.
2. Gently lie back on a diagonal with your head on the edge of the hammock.
3. Bring your feet in and stretch them out, so you are lying on a diagonal. This is the traditional way to relax in a conventional hammock.

NOTE: Do not climb into your hammock feet first.



CARING FOR YOUR HAMMOCK

To prolong the lifespan of your Two Trees hammock it is best to store away when not in use, as the sun and rain will deteriorate the fabric over time. If using near the sea it is important to rinse regularly.

Prior to washing your hammock, remove hooks and tie a loose single knot in the end strings at both ends. Cold water machine wash with regular cycle and non-bleach detergent. Remove the hammock immediately after the spin cycle, and hang to dry. Do not tumble dry.

STORING YOUR HAMMOCK

When storing your Two Trees hammock make sure hammock is clean and completely dry.

To prevent tangles, place a knot in each end string. Fold the hammock in half, with end strings together. Then fold the edges of the hammock to the centre, and roll the hammock up starting with the end strings and gently tuck into storage bag. Store in a dry place.

