




PRODUCT MANUAL

HAMMOCK HANGING KIT

TT501HK



Kit includes;

- » 2 x 4m nylon cords
- » 2 x zinc plated steel clamp hooks
- » 2 x zinc plated steel figure-eight hooks

250KG MAX. WEIGHT LOAD

SUITABLE FOR TEMPORARY HAMMOCK INSTALLATIONS



WARNING

Read instructions before use and keep for future reference. Failure to read these instructions before use can lead to an increased risk of injury. When installing, always check with a qualified builder for safety. Two Trees will only guarantee the performance of this product when used with other Two Trees products. i.e. if non Two Trees hammocks or stand are used, the guarantee is void.

Thank you for purchasing a Two Trees Hammock Hanging Kit.

We at Two Trees know the importance of spending time relaxing. Hence we've developed a range of quality hammocks and convenient accessories that come with easy to follow instructions so that you will be relaxing in no time. It is important to read all instructions before use and take care when using your hammock. Please ensure that you adhere to the following safety measures to get the maximum enjoyment from your new hammock.



WARNING

Read instructions before use and keep for future reference. Failure to read these instructions before use can lead to an increased risk of injury. When installing, always check with a qualified builder for safety.


CAUTION AND SAFETY INSTRUCTIONS

1. Assembly must be carried out by an adult.
2. Ensure hammock is fully assembled before use.
3. **DO NOT** exceed the maximum load of 250kgs.
4. **DO NOT** climb into hammock feet first.
5. **DO NOT** stand in hammock.
6. **DO NOT** dive into or jump about in hammock.
7. **DO NOT** stick your head through the suspension cords.
8. Keep suspension cords as straight as possible, **DO NOT** twist.
9. **DO NOT** use damaged or weakened hammock hanging accessories.
10. Hammock fabrics and accessories will wear over time and use. Always check the loading capacity and condition of parts before use.
11. Hammocks are not designed for swinging, playing, climbing or to be used as a children's toy.
12. **DO NOT** leave children or pets unattended in or near the hammock.
13. Hammock fabric, suspension cords and hanging accessories will become worn over time and use. Always inspect prior to use and **DO NOT** use if items show signs of damage or weakness.
14. Always check the loading capacity before use.
15. Keep hammock clear of obstructions.
16. Allow a minimum clearance of 50 cm around the perimeter of your hammock when in use (Fig. 1).
17. Only use the hammock on level floors with shock-absorbing properties such as grass or sand to minimise the risk of injury in case of an accident. **DO NOT** use on slippery or hard surfaces, jagged rocks, or on a slope.
18. Never use a free standing brick wall to hang your hammock.
19. Only use Two Trees accessories for hanging your hammock.
20. **DO NOT** modify hammock. Hammock must be used in accordance of this manual.
21. **DO NOT** smoke in or around the hammock. Keep away from heat or flames.
22. **DO NOT** use whilst wearing shoes, clothing, jewellery or accessories that have a hook and loop fastener.
23. **DO NOT** use near sharp objects.
24. A copy of this manual must be provided should the hammock transfer ownership.

SAFETY INSTRUCTIONS



Before each use, check the hammock and hanging accessories are free of damage. Do not alter, or tamper with the hammock in any way. Do not use if the item shows signs of damage or weakness. If using trees, ensure they are alive and sturdy.



DO NOT twist or knot suspension cords when hanging.



Hammocks will stretch by 5-10% after the first few uses. Adjustments can be made after each use to keep you and your hammock safe to use.




DO NOT exceed the maximum load of 250kgs. **DO NOT** sit in a hammock like a chair or on its edge. The hammock can flip, causing somersault backward.



DO NOT leave children or pets unattended in or near the hammock.




DO lying diagonally across the hammock, with this the fabric opening up allowing your body to be firmly supported whilst the hammock contours to your body.




DO NOT hang the hammock flat. It makes it unstable and prone to flipping. The ideal hammock setup should be installed with a sag that forms a banana-shaped curve at approx 110 degrees.

SELECTING THE LOCATION



BETWEEN
TREES



BETWEEN
TWO POSTS




For more information on our Two Trees range, please refer to the Two Trees website (www.twotreeshammocks.com.au) or scan the QR code.

THE TWO TREES HAMMOCKS RANGE INCLUDES



CLEARANCE




Allow a minimum clearance of 50 cm around the perimeter of your hammock when in use. <Fig.1>

FIXING POINTS

To hang your Two Trees hammock, you will require two fixed points, such as trees, beams or posts. Alternatively you can purchase a Two Trees Universal Stand. Consult a qualified builder if unsure.

Your Two Trees hammock will require a minimum of **3 metres** between fixing points to get the ideal shape. Rope may be needed to attach one end of the hammock, it is recommended to use a double piece to avoid the hammock twisting.

For longer distances, simply add a fixing strap or some rope and increase the height of the anchor point by approximately 60cm for every additional metre in length.




* Dimensions is for recommendation only.

Depending on the hammock the angle will vary. Conventional hammocks are hung with sag like a banana curve at approx. 110 degrees. Rod hammocks are hung taut at approx. 150 degrees.

Do not hang the hammock flat. We recommend that the lowest hang point before lying in your hammock exceeds no more or less than 70cm.



WARNING: Never use a free standing brick wall to hang your hammock.



TEMPORARY INSTALLATIONS

For temporary installations, such as trees or beams, we recommend using the Two Trees hammock hanging kit (TT501HK). For more information about our installation products please visit our website (www.twotreeshammocks.com.au)

- 1** Place the cord around the pole or tree, then thread through the figure eight hook.



- 2** Thread the cord through the clamp hook and secure at desired length.



- 3** Repeat process for other side of the hammock. Ensure both hooks are secure, then place hammock ends over hooks.



HOW TO RELAX IN YOUR HAMMOCK

1



Open the hammock fabric in the centre of the hammock and slowly and safely sit in the middle as you would in a chair.

2



Gently lie back on a diagonal with your head on the edge of the hammock.

3



Bring your feet in and stretch them out, so you are lying on a diagonal. This is the traditional way to relax in a classic style hammock.



WARNING:
DO NOT EXCEED THE
MAXIMUM LOAD OF 250KGS

CARING FOR YOUR HAMMOCK

Do not soak or wash in products containing enzymes or bleaches. Cold hand wash with mild detergent. Line dry in shade. Do not tumble dry. Do not iron. Do not dry clean.

Prior to washing, tie a loose single knot in the end strings at both hanger ends.

To prolong the life of your hammock, store it away when not in use, as prolonged exposure to sun and rain will deteriorate the fabric over time. If using near the sea, rinse your hammock regularly and allow it to dry thoroughly before reuse.

STORING YOUR HAMMOCK

When storing your Two Trees hammock make sure hammock is clean and completely dry.

To prevent tangles place a knot in each suspension cord. Fold the hammock in half, with suspension cords together. Then fold the edges of the hammock to the centre, and roll the hammock up starting with the suspension cords. Store in a dry place.



